
















SL-910DF/Z102/RB

Installation Details		Installation Diagram • Caution	
1	Optional parts installation 【Filter】		
	2 Put a filter in hood and put it back.		
	<p>The filter sandwiches it between hood and the fixture and is put on.</p> <p>A filter, please be careful not to drop on the occasion of desorption of hood.</p>		
1	Connect the bundled dedicated Driver to the connector of Luminaire		
	2 Please connect according to the description of the power supply.		
	3 Install a dedicated driver on the ceiling		
	Be sure to turn off the power before working		
	Connect the connector securely. If you remove it pull while holding the lock. Do not connect or disconnect the connector while the power is on. (Cause of trouble)		
	Do not touch the metal terminals on the inside of the connector directly with your hands.		

Installation Details		Installation Diagram • Caution	
1	Installation to ceiling		
	2 Install the fixture to the mounting frame.		
	Make sure to install the safety wire to the mounting frame securely.		
	Use clean soft cloth to clean up and maintain inner side of the body.		
	The description of a power supply.		
	Make sure the fixture will not touch any objects in ceiling.		
		