
### Installation Guide | Lighting Fixture

ADJUSTABLE DOWNLIGHT

## MMP-100A/30B/DL/3



To install	the fixtui	re sa	fely《 Read carefully and follow all the instructions in the guide 》
① Warning :	Failure to in	nstall t	the fixture properly could result in personal injury.
( Caution :	Failure to in	nstall t	the fixture properly could result in property damage.   ① : Strict observance
Before installation	<b>⚠</b> Warning	0	The fixture is for indoor use only in general conditions. This fixture can only be installed on a horizontal ceiling. Can not be used following conditions (Causes of falling, electrocution and fire)  Inclined, uneven surface  Insulated inside of ceiling  Ambient temperature under 0°C and over 35°C  Ceiling which can't hold the fixture weight  Outside  On the floor  Vibrated or shocked areas  Areas get direct sunlight  Dusty areas, corrosive gas outbreaks areas  Please contact if you are not able to judge whether installation environment is suitable to the places or not.
	<b>Caution</b>	0	Please follow the fixtures' indication or specification for the distance of irradiated area. (Causes of change in shape, change in color of irradiated objects)
For electric wiring	<b>N</b> Warning	0	Only qualified person may work on electric wiring and equipment. (Cause of accidents)
		0	Use alternating current. Please follow rating plate of fixtures for power supply frequency. (Cause of electrification • fire) (50Hz • 60 Hz common use for ballasts and incandescent lamp fixtures)
		0	Be sure power supply voltage is within $\pm 6\%$ mentioned in rating plate or the guide. (Causes of short life of lamps $\cdot$ electrification $\cdot$ fire)
		0	Be sure all the wires and codes are not damaged. (Causes of falling • damage)
At lighting fixture installation	<b>⚠</b> Warning	0	Please follow the fixtures' instruction or this guide to install the fixture and lamp. (Causes of falling • electrification • fire)
		0	Switch off the power when installing the lamp. (Causes of electrification)
		0	Do not touch the fixture when switch is on or just turn off the switch because of high temperature.
		0	Do not put or cover the fixture by any cloths, papers, or insulators.(Causes of not lighting • fire)
		0	Do not place any metallic or flammable objects. (Cause of electrification • fire • broken fixture)
		0	Make sure to install all the parts of fixtures besides installation and mounting parts will not touch with any objects both inside and outside of ceiling such as lighting track, etc. (Causes of falling • electrification • fire)
		0	Do not dismount or remodel fixtures. (Cause of electrification • fire • falling • broken fixtures)
		0	Do not operate with wet hands.
		0	If you smell smoke, see smoke, or find anything unusual, please turn the switch off and ask construction companies to repair. (Cause of electrification • fire)
	<b>⚠</b> Caution	0	Make sure the construction will not affect any fire prevention systems such as sprinkler by heat from the fixture. (Causes for improper operation)

# **ModuleX**


Installation Guide Lighting Fixture

MUSEUM platform / adjustable down light

To install ModuleX safety

#### MMP-100A/30B/DL/3

	Installation Details	Installation Diagram	Caution
	Wiring connection  Please connect according to the description of a power supply.		Wiring diagram  PE N L  DC900mA MAX  37.9V +RED
<u> </u>	When connecting the driver, careful attention should be paid to connecting + and		-BLACK LED
	Metal part in a cable point, please don't touch with bare hand directly.		CAUTION! Do not reverse polarity!  + RED - BLACK
	Optional parts installation		<u></u>
1	Turn around the body.	2 Body	UP to 3FILTERS OPTION HOLDER
2	Pull out the body from the hood.	<del>0</del> 1	ST TO STIETERS THOUBER
3	Turn around the option holder, and put out .		+
4	Put a filter in hood.	Hood	
5	Turn around the option holder, and put in.	OPTION HOLDER	' O × '
<u> </u>	Please attention that the sharpener lens is counted two pieces of filter lenses.	UP to FILTER 4	Sharpner lends
₫	Don't put in the filters than the rule number of pieces. Causes of falling and damage.	Inner HOOD	
	Tilting angle setting		
1	Please loose a screw by the hexagonal wrench, and unrock.	Ō	2
2	Please regulate a point of view to a scale.		
	Please use an attached hexagon wrench by all means.	hexagonal wr	rench



(COIIIaCI)

#### Concord Lighting

5/F, Longbow House,14-20 Chiswell Street, London, EC1Y 4TW, UK Tel : +44-01273-616649

#### ModuleX Inc.

#21 AraiBldg, 1-20-6 Ebisu-Minami Shibuya-ku, Tokyo Tel: +81-3-5768-3131