
Tracklight

MMP-130S/5H/1E/40B/Z2/3

FOR USE WITH EUTRAC CORP, Series 225, TRACK SYSTEM ONLY. EUTRAC lighting track is sold separately.



To install the fixture safely 《 Read carefully and follow all the instructions in the guide 》 S : Prohibited Warning : Failure to install the fixture properly could result in personal injury. A Caution : Failure to install the fixture properly could result in property damage. **1** : Strict observance The fixture is for indoor use only in general conditions. This fixture can only be installed on a horizontal ceiling. Before Warning Can not be used following conditions (Causes of falling, electrocution and fire) installation Inclined, uneven surface ●Ambient temperature under 0°C and over 35°C •High humidity Ceiling which can't hold the fixture weight On the wall Outside \bigcirc On the floor Places affected by wind or air-conditioner machine ●Vibrated or shocked areas ●Near fire Areas get direct sunlight Dusty areas, corrosive gas outbreaks areas Please contact if you are not able to judge whether installation environment is suitable to the places or not. Please follow the fixtures' indication or specification for the distance of irradiated area. 0 Caution (Causes of change in shape, change in color of irradiated objects) \Lambda Warning 🚺 For electric Only gualified person may work on electric wiring and equipment. (Cause of accidents) wiring Use alternating current. Please follow rating plate of fixtures for power supply frequency. 0 (Cause of electrification • fire) (50Hz • 60 Hz common use for ballasts and incandescent lamp fixtures) 0 Be sure power supply voltage is within ±6% mentioned in rating plate or the guide. (Causes of short life of lamps • electrification • fire) 0 Be sure all the wires and codes are not damaged. (Causes of falling • damage) 0 Please follow the fixtures' instruction or this guide to install the fixture and lamp. (Causes of falling • electrification • fire) Warning At lighting fixture 0 Switch off the power when installing the lamp. (Causes of electrification) installation \bigcirc Do not touch the fixture when switch is on or just turn off the switch because of high temperature. \bigcirc Do not put or cover the fixture by any cloths, papers, or insulators.(Causes of not lighting • fire) \bigcirc Do not place any metallic or flammable objects. (Cause of electrification • fire • broken fixture) Make sure to install all the parts of fixtures besides installation and mounting parts will not touch with any 0 objects both inside and outside of ceiling such as lighting track, etc. (Causes of falling • electrification • fire) \bigcirc Do not dismount or remodel fixtures. (Cause of electrification • fire • falling • broken fixtures) \odot Do not operate with wet hands. If you smell smoke, see smoke, or find anything unusual, please turn the switch off and ask construction 0 companies to repair. (Cause of electrification • fire) Make sure the construction will not affect any fire prevention systems such as sprinkler by heat from the fixture. ▲ Caution 0

(Causes for improper operation)

ModuleX

Installation Guide

Lighting Fixture

Tracklight

MMP-130S/5H/1E/40B/Z2/3

Installation Details	Installation Diagram	Caution			Installation Details	Installation Diagram
Attaching luminaire to track 1 Lower the cover of the power supply box 2 Turn the lever to the left (turn off the power) 3 Insert luminaire into track Insert the luminaire surely into the track. There is a danger of falling if there is incompleteness. Insert the lever to the right (turn on the power) 4 Turn the lever to the right (turn on the power)		FOR USE WITH EUTRAC CORP, Series 225, TRACK SYSTEM ONLY. Lighting track is sold separately. This fixture can be attached to the 3 circuitrails, but only 1 circuit can be used for power supply. Please do not attach the fixture to the 3 circuitrails in which more than 1 circuit are occupied for power supply. It may cause tripping the circuitbreaker. Connect with only N and L1 recommended. Image: Connect with only N and L1 recommended. <	2	1 2 3 4 5	Optional parts installation Turn around the body. Pull out the body from the hood. Turn around the option holder, and put out . Put a filter in hood. Turn around the option holder, and put in. Please attention that the sharpener lens is counted two pieces of filter lenses. Don't put in the filters than the rule number of pieces.	Body Body LHood 2 Option Holder 3 Filter
 position. Failure to do so may cause a fall or fire. Raise the cover of the power su box If you can not raise the cover, there is a possibility that the luminaire is not securely fix 	<u> </u>	The terminals are connected internally as shown in the right circuit diagram. $ \underbrace{\mathbf{FF}}_{\text{Lever position indication}} \underbrace{\mathbf{ON}}_{\text{Constraint}} $		ſ∫d	Causes of falling and damage. Align the markings of the hood and the body, please turn it clockwise until it clicks.	
Please try installing again. Please try installing again. Do not install on walls and floc Adjustment of irradiation direct Grasp the fixture and adjust the irradiation direction direction direction.		×wall ×floor		1	Tilting angle setting Please loose a screw by the hexagonal wrench, and unrock. Please regulate a point of view to a scale. Please use an attached hexagon	Pan lock
1 the irradiation direction Image: Do not forcibly move beyond the movable range Please adjust the fixture after turning off the power and cooling the fixture	10°				wrench by all means.	

Concord Lighting 5/F, Longbow House,14-20 Chiswell Street, London, EC1Y 4TW, UK Tel : +44-01273-616649

