








MMP-100S/1H/MS/30B/Z2/3
















	Weight	Light Source LED module
	0.87kg	Dedicated Driver Constant Current
	Rotate degrees	Driver
		Input Voltage 220V/240V±6%
		50Hz/60Hz
		Input Current 0.200A/0.185A
		Power Consumption 39.7W/39.9W
		Dimming method 0-10V
		Fixture
		Input Voltage 37.9V
		Input Current 0.9A
		Dimmer
		SR-2830AS-1-10
		OPTION
		Full diffuser lens filter MLA-100/DF01
		Semi diffuser lens filter MLA-100/DS02
		Full spread lens filter MLA-100/SF01
		Semi spread lens filter MLA-100/SS01
		Edge control filter MLA-100/EC02
		Sharpener lens filter MLA-100/SH01
		(available only for narrow distribution)

ModuleX

Installation Guide

Lighting Fixture

MMP-100S/1H/MS/30B/Z2/3

To install the fixture safely 《 Read carefully and follow all the instructions in the guide 》				
 Warning : Failure to install the fixture properly could result in persona l injury.		 : Prohibited		
 Caution : Failure to install the fixture properly could result in property damage.		 : Strict observance		
Before installation			The fixture is for indoor use only in general conditions. Can not be used following conditions (Causes of falling, electrocution and fire) ●Areas get direct sunlight ●Plases affected by wind or air-conditioner mashine ●On the floor ●Vibrated or shocked areas ●Outside ●Ambient temperature under 0℃ and over 35℃ ●Near fire ●Ceiling which can't hold the fixture weight ●High humidity ●Dusty areas, corrosive gas outbreaks areas ●Inclined, uneven surface Please contact if you are not able to judge whether installation environment is suitable to the places or not.	
				
			Keep equipment away from electronic medical devices such as pacemakers	
			When it is lit, it becomes hot immediately after it is turned off. Install it in a place that cannot be easily touched.	
			Even when using it indoors, do not use it in a place where there is a sulfur component around the equipment. (Sulfur components may also be contained in some foods, chemicals, papers, rubber products, and car exhaust gas.)	
			Please follow the fixtures' indication or specification for the distance of irradiated area. (Causes of change in shape, change in color of irradiated objects)	
For electric wiring			Only qualified person may work on electric wiring and equipment.(Cause of accidents)	
			Please use a compatible power supply and compatible driver. (Cause of non-lighting / fire)	
			Be sure power supply voltage is within ±6% mentioned in rating plate or the guide. (Causes of short life of lamps•electrification•fire)	
			Be sure all the wires and codes are not damaged. (Causes of falling•damage)	
			Do not perform live-line construction. There is a risk of electric shock or product failure.	
			Do not install other electronic devices (devices that use a motor such as a ventilation fan) in the same circuit as it may lead to equipment failure.	
At lighting fixture installation			Please follow the fixtures' instruction or this guide to installthe fixtue and lamp. (Causes of falling•electrification•fire)	
			For models that come standard with a safety clip to prevent dropping due to an earthquake, etc., be sure to follow the instructions in this manual and install the product securely.	
			Be sure to turn off the power when installing the fixture or lamp. (Cause of electric shock)	
			Do not touch the fixture when switch is on or just turn off the switch because of high temperature.	
			Do not put or cover the fixture by any cloths, papers, or insulators.(Causes of not lighting•fire)	
			Do not put metal or burning objects in the gaps of the equipment. (Causes of electric shock, fire, and equipment failure)	
			Do not dismount or remodel fixtures. (Cause of electrification • fire • falling • broken fixtures)	
			Do not operate with wet hands.	
			Do not grab and lift wires or cables that are not the product itself. It may be damaged.	
			If you smell smoke, see smoke, or find anything unusual, please turn the switch off and ask construction companies to repair. (Cause of electrification•fire)	
			Use protective equipment such as clean gloves when installing and removing equipment. (Cause of injury)	
			Install so that the heat of the equipment does not affect the fire protection equipment such as sprinklers. (Cause of malfunction)	
			Please note that noise may enter the device if it is lit near a communication device such as a radio.	

MMP-100S/1H/MS/30B/Z2/3

	Installation Details	Installation Diagram • Caution
	<div>Installation</div> <div>1 Prepare a mounting surface with no irregularities and a magnet attached</div> <div>2 Attach the magnet case slowly close to the mounting surface</div> <div>3 Secure the included safety clip securely with screws within 300 mm from the fixture</div>	<div><div>1 Mounting surface</div><div>2</div><div>3 within 300mm</div></div>
	<div>After installing the fixture, make sure that it is securely attached</div> <div>If the magnet case is brought closer to the mounting surface, the magnet may crack or damage the mounting surface</div>	
	<div>1 Connect the bundled dedicated Driver to the connector of Luminaire</div> <div>2 Please connect according to the description of the power supply.</div> <div>3 Install a dedicated driver on the ceiling</div>	<div><div>1a</div><div>Driver side Lock Luminaire side</div></div>
	<div>Be sure to turn off the power before working</div> <div>Connect the connector securely. If you remove it pull while holding the lock. Do not connect or disconnect the connector while the power is on. (Cause of trouble)</div> <div>Do not touch the metal terminals on the inside of the connector directly with your hands.</div>	<div>Wiring diagram</div> <div>AC Power 50/60Hz</div> <div>NTC-SRP-2007-50CC</div> <div>LIGHTING FIXTURE</div> <div>0/1-10V Control Unit</div> <div>Dips to set the operation current 1 2 3 4</div> <div>Do not change settings</div>
	<div>Adjustment of irradiation direction</div> <div>1 Grasp the fixture and adjust the irradiation direction</div>	<div><div>Range of movement</div><div>10° 90° 380°</div><div>Direction of irradiation</div><div>Do not expose instruments upwards It is dangerous because dust etc. will be heated and accumulated</div></div>
	<div>Do not forcibly move beyond the movable range</div> <div>Please adjust the fixture after turning off the power and cooling the fixture</div>	

	Installation Details	Installation Diagram • Caution
	<div>Optional parts installation</div> <div>1 Turn around the hood.</div> <div>2 Pull out the hood from the body.</div> <div>3 Turn around the option holder, and put out .</div> <div>4 Put a filter in hood.</div> <div>5 Turn around the option holder, and put in.</div>	<div><div>1b</div><div>Body Hood</div><div>2</div><div>3 5 OPTION HOLDER</div><div>UP to 2FILTERS</div><div>4 FILTER</div><div>1c</div><div>UP to 2FILTERS</div><div>OPTION HOLDER</div><div>Sharpner lens</div><div>1d</div><div>cut</div></div>
	<div>Please attention that the sharpener lens is counted two pieces of filter lenses.</div> <div>Don't put in the filters than the rule number of pieces. Causes of falling and damage.</div> <div>To rotate the holder, please wear a flat head screwdriver at the cut.</div> <div>Align the markings of the hood and the body, please turn it clockwise until it clicks.</div>	
	<div>Tilting angle setting</div> <div>1 Please loose a screw by the hexagonal wrench,and unrock. Please regulate a point of view to a scale.</div>	<div><div>Pan lock</div><div>Tilt lock</div></div>
	<div>Please use an attached hexagon wrench by all means.</div>	